



**WARNING!!!** To avoid electrical shock, turn OFF power before installation. If junction box opening is not fully covered by canopy, canopy trim plate **MUST** be installed.

1. Connect 120V power leads from junction box to wires from transformer(s) inside canopy. Secure the ground lead to ground wire or a grounded surface.
2. Secure canopy and canopy trim plate to ceiling.
3. Reassemble canopy cover.
4. Connect Jesco Quick Adapt Pendant or Quick Adapt Spot.