

LED RECESSED DOWNLIGHTS • ARCHITECTURAL SERIES

INSTALLATION INSTRUCTIONS



READ AND FOLLOW ALL SAFETY INSTRUCTIONS



WARNING - RISK OF FIRE AND ELECTRICAL SHOCK. FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY. FIXTURE IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE, LOCAL AND FEDERAL SPECIFICATIONS. DISCONNECT POWER AT ELECTRICAL PANEL BEFORE SERVICING. RETAIN THESE INSTRUCTIONS FOR MAINTENANCE REFERENCE.

CUT-OUTS

MODEL #	CUTOUT
RLH-6130A	6 ½"
RLH-6130R	6 ½"
RLH-8150A	8"
RLH-8150R	8"

EACH FIXTURE HAS SELECTABLE LED COLOR AND LIGHT OUTPUT

- LED Color located on LED engine
- Light Output located on driver
- Prior to closing the fixture, LED color and light output must be set to specification per lighting plan

